

用户手册

[SBC-PH8700]

历史版本

Rev.	Note	Author
20160902	Initial	Sandy

目录

历史版本	2
目录	3
Release Note	5
1. 镜像版本	5
2. 功能列表	5
3. 已知问题	6
第 1 章 快速启动	7
1.1 烧写镜像到 SD 卡	7
1.2 从 SD 卡启动系统	8
1.3 从 EMMC 启动系统	9
第 2 章 功能测试	10
2.1 LED 测试	10
2.2 RTC 测试	10
2.3 EEPROM 测试	11
2.4 EMMC 测试	12
2.5 ADC 测试	12
2.6 HDMI 测试	13
2.7 HDMI AUDIO 测试	13
2.8 LCD 测试	13
2.9 背光测试	13
2.10 触摸屏测试	13
2.11 串口测试	14
2.11.1 UART1	14
2.11.2 UART2	14
2.11.3 UART4	14
2.12 RS485 测试	14
2.12.1 RS485-2 和 RS485-3	14
2.13 CAN 测试	15
2.14 网络测试	15
2.15 USB 测试	16
2.15.1 Host 测试	16

2.15.2	OTG 测试	16
第 3 章	系统编译	18
3.1	配置编译环境	18
3.2	编译 UBOOT	18
3.2.1	获取 uboot 源码.....	18
3.2.2	编译并烧写镜像到 SD 卡	18
3.2.3	编译并烧写镜像到 EMMC.....	18
3.3	Kernel.....	19
3.3.1	获取内核源码	19
3.3.2	编译并烧写镜像到 SD 卡	19

Release Note

1. 镜像版本

SBC-PH8700_Shipment_Image_SDcard_Rev01.img

SBC-PH8700_Shipment_Image_EMMC_Rev01.img

2. 功能列表

SBC-PH8700				
Feature List	Schematic Page#	On-Chip Peripherals	On-Board Peripherals	Detail Functions(existing)
u-boot version	2015.09			Supports kernel boot
kernel version	4.1.6			Supports all below functionality
Filesystem	Debian			Default root file system used by debian
CPU	PH8700-U5	AM3358_ZCZ		Null
DDRAM	PH8700-P8-U12	DDR	MT41K256M16HA-125	Can access read write and run code
PMIC	PH8700-P3-U2	I2C0	TPS65217	Null
eMMC	PH8700-P9-U13	MMC1	MTFC4GLDEA	Can access read write and boot
SDCard	Null			
MicroSD_(TF)	SPH1800-P6-TF1	MMC0	Null	Can access read write and boot
External-RTC	SPH1800-P9-U55	I2C0	RX-8025TUB	can read write and keep time off power
Integrited-RTC	PH8800-u11	RTC	Null	can read write and keep time off power
LEDs	PH8800-p10-D3/D	gpio	Null	System can control LED to light or not
LCD	SPH1800-P9-J9	RGB	Null	Can show picture on the screen
Backlight	SPH1800-P9-J9	PWM	Null	System can control the LCD backlight
TouchScreen	SPH1800-P9-J9	ADC-TSC	Null	System use touchscreen
EEPROM	PH8800-p8-u14	MMC1	MTFC4GACAAAM-4M	Can access read write
CAN	SPH1800-p8-J61	CAN1	MC33901WEF	System can send and receive data

				between two board
UART-0	SPH1800-p7-CN4	UART0	NULL	System can send and receive data in loopback mode
UART-1	SPH1800-p7-J4	UART5	MAX3232CUE+	System can send and receive data in loopback mode
UART-2	SPH1800-p13-J58	UART3	Null	System can send and receive data in loopback mode
UART-4	SPH1800-p13-J58	UART1	MAX3232CUE+	System can send and receive data in loopback mode
RS485-2	SPH1800-p8-u5	SPI0	SC16IS752IPW	System can send and receive data between two board
RS485-3	SPH1800-p8-u5	SPI0	SC16IS752IPW	System can send and receive data between two board
USB-Host	SPH1800-p11-p3	USB1	Null	Can recognize U disk by USB host
USB-OTG	SPH1800-p11-j13	USB0	Null	Can recognize U disk in host mode, and can work as usb ethernet in device mode
Ethernet-1	PH8800-P9-U9	RGMII1	KSZ9031RNXIA	Can ping the server
Ethernet-2	SPH1800-P12-J17	RGMII2	AR8035	Can ping the server
HDMI	SPH1800-P10-U34	I2C0	TDA19988BHN/C1,551	Can show picture on the screen
Audio	SPH1800-P10-U34	I2C0	TDA19988BHN/C1,551	can play wav


3. 已知问题

Known issue List	Detail
LCD	4.3 inch screen turn white for a while in boot 7 inch screen blink several times when boot
HDMI	Not shown correctly Not support Sony HDMI display


第1章 快速启动

1.1 烧写镜像到 SD 卡


- 首先，你需要准备一张不小于 2G 的 SD 卡
- 然后，你需要从 <https://sourceforge.net/projects/win32diskimager/> 下载并安装 Win32 Disk Imager



- 选择需要烧写的镜像，SBC-PH8700_Shipment_Image_SDcard_Rev01.img:



- 点击 Write 烧写镜像:



1.2 从 SD 卡启动系统

- 在 PC 上安装串口软件（例如 SecureCRT），选择正确的端口号，波特率 115200，8 位数据位，1 位停止位，无奇偶校验
- 用 USB 转 TTL 模块把板子上的 DEBUG 接口(CN4)和 PC 相连
- 把 Micro SD 卡插入板上的插槽 TF1
- 按下按键 S3，用 5V,2A 的电源，给板子供电(J1)，上电复位后松开 S3
- 系统启动完毕之后，串口显示如下

```
[ 4.779552] systemd[1]: Starting Journal Service...
[ 4.802315] systemd[1]: Started Journal Service.
[ 5.040992] systemd-udevd[144]: starting version 215
[ 5.360032] systemd-journald[143]: Received request to flush runtime journal from PID 1
[ 6.677796] remoteproc0: failed to load am335x-pm-firmware.elf
[ 6.733794] remoteproc0: powering up wkup_m3
[ 6.739527] remoteproc0: Direct firmware load for am335x-pm-firmware.elf failed with error
[ 6.895292] remoteproc0: Falling back to user helper
[ 7.275365] remoteproc0: request_firmware failed: -11
[ 7.281803] remoteproc0: rproc_boot failed
[ 8.031991] net eth0: initializing cpsw version 1.12 (0)
[ 8.114081] net eth0: phy found : id is : 0x4dd072
[ 8.140049] net eth1: initializing cpsw version 1.12 (0)
[ 8.224126] net eth1: phy found : id is : 0x4dd072
[ 8.919773] c_can_platform 481cc000.can can0: bit-timing not yet defined
[ 8.973742] c_can_platform 481cc000.can can0: failed to open can device
[ 9.665888] random: nonblocking pool is initialized
[ 11.114500] cpsw 4a100000.ethernet eth0: Link is up - 100Mbps/Full - flow control rx/tx
```

```
Debian GNU/Linux 8 embest ttyS0
```

```
www.embest-tech.com
```

```
default username:password is [root:root]
```

```
embest login:
```

输入用户名和密码 root 登录:

```
Debian GNU/Linux 8 embest ttyS0
```

```
www.embest-tech.com
```

```
default username:password is [root:root]
```

```
embest login: root
```

```
Password:
```

```
Linux embest 4.1.6 #1 PREEMPT Tue Sep 27 10:47:01 CST 2016 armv7l
```

```
The programs included with the Debian GNU/Linux system are free software;
the exact distribution terms for each program are described in the
individual files in /usr/share/doc/*/copyright.
```

```
Debian GNU/Linux comes with ABSOLUTELY NO WARRANTY, to the extent
permitted by applicable law.
```

```
root@embest:~#
```


1.3 从 EMMC 启动系统

将 SBC-PH8700_Shipment_Image_EMMC_Rev01.img 拷贝到 U 盘；

参考 [1.2](#)，先从 SD 卡启动系统，再将 U 盘插入 USB 接口（P3）；

在串口终端输入：

```
root@embest:~# ls /dev/sd*
```

```
/dev/sda /dev/sda1
```

```
root@embest:~# mount /dev/sda1 /mnt/
```

```
root@embest:~# dd if=/mnt/SBC-PH8700_Shipment_Image_EMMC_Rev01.img of=/dev/mmcblk1
```

注意：烧写时间较长，请耐心等待...

烧写结束后，上电复位并启动系统（不用按 S3）

第2章 功能测试

首先, 请参考[第一章 1.1](#), 把系统启动起来. 然后跟随下面的指引测试各项功能.

2.1 LED 测试

用户能够控制 SOM-PH8700 上的 LED (D2,D3) 指示灯. 在终端中执行以下命令来进行测试; (其中 D2 对应 user_leds_d2, D3 对应 user_leds_d3)

熄灭 LED:

```
root@embest:~# echo 0 > /sys/class/leds/user_leds_d2/brightness
```

```
root@embest:~# echo 0 > /sys/class/leds/user_leds_d3/brightness
```

点亮 LED:

```
root@embest:~# echo 1 > /sys/class/leds/user_leds_d2/brightness
```

```
root@embest:~# echo 1 > /sys/class/leds/user_leds_d3/brightness
```

2.2 RTC 测试

在串口终端输入:

查看当前时间:

```
root@embest:~# date
```

```
Sat Jan 1 00:02:07 UTC 2000
```

设置时间 2016 年 3 月 9 日 10 时 46 分:

```
root@embest:~# date 030910462016
```

```
Wed Mar 9 10:46:00 UTC 2016
```

把系统时钟写入 RTC:

```
root@embest:~# hwclock -w
```

读取 RTC:

```
root@embest:~# hwclock
```

```
Wed 09 Mar 2016 10:46:23 AM UTC -0.432561 seconds
```

可以看到, 硬件时钟 RTC 被设置成 2016 年 3 月 9 日, 系统时钟被保存到硬件时钟里。

重启系统并查看时间:

```
root@embest:~# date
```

```
Wed Mar 9 10:46:45 UTC 2016
```

2.3 EEPROM 测试

在串口终端输入以下命令：

```
root@embest:~# ./eeprom_test
```

```
data will write to EEPROM at 0x400
```

```
00 01 02 03 04 05 06 07 08 09 0a 0b 0c 0d 0e 0f
10 11 12 13 14 15 16 17 18 19 1a 1b 1c 1d 1e 1f
20 21 22 23 24 25 26 27 28 29 2a 2b 2c 2d 2e 2f
30 31 32 33 34 35 36 37 38 39 3a 3b 3c 3d 3e 3f
40 41 42 43 44 45 46 47 48 49 4a 4b 4c 4d 4e 4f
50 51 52 53 54 55 56 57 58 59 5a 5b 5c 5d 5e 5f
60 61 62 63 64 65 66 67 68 69 6a 6b 6c 6d 6e 6f
70 71 72 73 74 75 76 77 78 79 7a 7b 7c 7d 7e 7f
80 81 82 83 84 85 86 87 88 89 8a 8b 8c 8d 8e 8f
90 91 92 93 94 95 96 97 98 99 9a 9b 9c 9d 9e 9f
a0 a1 a2 a3 a4 a5 a6 a7 a8 a9 aa ab ac ad ae af
b0 b1 b2 b3 b4 b5 b6 b7 b8 b9 ba bb bc bd be bf
c0 c1 c2 c3 c4 c5 c6 c7 c8 c9 ca cb cc cd ce cf
d0 d1 d2 d3 d4 d5 d6 d7 d8 d9 da db dc dd de df
e0 e1 e2 e3 e4 e5 e6 e7 e8 e9 ea eb ec ed ee ef
f0 f1 f2 f3 f4 f5 f6 f7 f8 f9 fa fb fc fd fe ff
```

```
data read from EEPROM at 0x400
```

```
00 01 02 03 04 05 06 07 08 09 0a 0b 0c 0d 0e 0f
10 11 12 13 14 15 16 17 18 19 1a 1b 1c 1d 1e 1f
20 21 22 23 24 25 26 27 28 29 2a 2b 2c 2d 2e 2f
30 31 32 33 34 35 36 37 38 39 3a 3b 3c 3d 3e 3f
40 41 42 43 44 45 46 47 48 49 4a 4b 4c 4d 4e 4f
50 51 52 53 54 55 56 57 58 59 5a 5b 5c 5d 5e 5f
60 61 62 63 64 65 66 67 68 69 6a 6b 6c 6d 6e 6f
70 71 72 73 74 75 76 77 78 79 7a 7b 7c 7d 7e 7f
80 81 82 83 84 85 86 87 88 89 8a 8b 8c 8d 8e 8f
90 91 92 93 94 95 96 97 98 99 9a 9b 9c 9d 9e 9f
a0 a1 a2 a3 a4 a5 a6 a7 a8 a9 aa ab ac ad ae af
b0 b1 b2 b3 b4 b5 b6 b7 b8 b9 ba bb bc bd be bf
c0 c1 c2 c3 c4 c5 c6 c7 c8 c9 ca cb cc cd ce cf
d0 d1 d2 d3 d4 d5 d6 d7 d8 d9 da db dc dd de df
```

```
e0 e1 e2 e3 e4 e5 e6 e7 e8 e9 ea eb ec ed ee ef
f0 f1 f2 f3 f4 f5 f6 f7 f8 f9 fa fb fc fd fe ff
```

写数据与读到的数据相同，测试通过；

2.4 EMMC 测试

在串口终端执行：

```
root@embest:~# touch emmc_read emmc_write
```

编辑 emmc_write:

```
root@embest:~# vi emmc_write
```

例如写入 “emmc write test”

写 emmc 命令：

```
root@embest:~# dd if=emmc_write of=/dev/mmcblk1
```

```
[ 68.358218] mmcblk1: p1 p2
```

```
0+1 records in
```

```
0+1 records out
```

```
16 bytes (16 B) copied, 0.0273767 s, 0.6 kB/s
```

读 emmc 命令：

```
root@embest:~# dd if=/dev/mmcblk1 of=emmc_read bs=1K count=10
```

```
10+0 records in
```

```
10+0 records out
```

```
10240 bytes (10 kB) copied, 0.00800079 s, 1.3 MB/s
```

查看 emmc_read:

```
root@embest:~# cat emmc_read
```

```
emmc write test
```

测试成功；

2.5 ADC 测试

在串口终端输入以下命令，采样值返回：

```
root@embest:~# cat /sys/bus/platform/devices/TI-am335x-adc/iio\:device0/in_voltage4_raw
571
```

```
root@embest:~# cat /sys/bus/platform/devices/TI-am335x-adc/iio\:device0/in_voltage5_raw
863
```

```
root@embest:~# cat /sys/bus/platform/devices/TI-am335x-adc/iio\:device0/in_voltage6_raw
863
```

```
root@embest:~# cat /sys/bus/platform/devices/TI-am335x-adc/iio\:device0/in_voltage7_raw
879
```

2.6 HDMI 测试

打开 SD 卡中 uEnv.txt 文件，修改 fdtfile=embest-SOM_PH8700-BB_SPH1800-HDMI.dtb

用 HDMI 数据线相连接显示设备并重新启动系统；

2.7 HDMI AUDIO 测试

连接 HDMI 设备，执行以下命令播放默认音频文件

```
root@embest:~# aplay /boot/firmware/audio_sample.wav
```

```
Playing WAVE '/boot/firmware/audio_sample.wav' : Signed 16 bit Little Endian, Rate 22050 Hz, Stereo
```

2.8 LCD 测试

连接显示屏到 J9:

4.3 寸屏:

打开 SD 卡中 uEnv.txt 文件，修改 fdtfile= embest-SOM_PH8700-BB_SPH1800-4.3inch_LCD.dtb

连接 4.3 寸屏并重新启动系统；

7 寸屏:

打开 SD 卡中 uEnv.txt 文件，修改 fdtfile= embest-SOM_PH8700-BB_SPH1800-7inch_LCD.dtb

连接 7 寸屏并重新启动系统；

2.9 背光测试

背光的亮度设置范围为（1—8），1 表示亮度最低，8 表示亮度最高，在串口终端下输入如下命令进行背光测试：

最暗：

```
root@embest:~# echo 1 > /sys/class/backlight/backlight/brightness
```

最亮：

```
root@embest:~# echo 8 > /sys/class/backlight/backlight/brightness
```

2.10 触摸屏测试

连接显示屏到 J9,在串口终端输入以下命令执行触摸屏校准程序：

```
root@embest:~# ts_calibrate
```

按照屏幕上提示，点击 “+” 图标 5 次完成校准。

2.11 串口测试

开发板上有 4 个串口，其中 UART0(CN4)为 debug 接口

2.11.1 UART1

短接 J4 第 2, 3 号接口:

```
root@embest:~# ./uart_test -d /dev/ttyS1 -b 115200
```

```
/dev/ttyS1 SEND: 1234567890
```

```
/dev/ttyS1 RECV 10 total
```

```
/dev/ttyS1 RECV: 1234567890
```

注意: **Ctrl+C** 中断串口测试

2.11.2 UART2

短接 J58 第 16, 17 号接口:

```
root@embest:~# ./uart_test -d /dev/ttyS2 -b 9600
```

```
/dev/ttyS2 SEND: 1234567890
```

```
/dev/ttyS2 RECV 10 total
```

```
/dev/ttyS2 RECV: 1234567890
```

注意: **Ctrl+C** 中断串口测试

2.11.3 UART4

短接 J58 第 14, 15 号接口:

```
root@embest:~# ./uart_test -d /dev/ttyS4 -b 9600
```

```
/dev/ttyS4 SEND: 1234567890
```

```
/dev/ttyS4 RECV 10 total
```

```
/dev/ttyS4 RECV: 1234567890
```

注意: **Ctrl+C** 中断串口测试

2.12 RS485 测试

2.12.1 RS485-2 和 RS485-3

分别短接 J62 的 7, 9 号引脚; 8, 10 号引脚(即 RS485-A3 to RS485-A2, RS485-B3 to RS485-B2):

串口终端输入如下命令 (在后台运行):

```
root@embest:~# ./uart_test -d /dev/ttySC1 -b 9600 -s "a" &
```

接着输入:

```
root@embest:~# ./uart_test -d /dev/ttySC0 -b 9600 -s "c"
```

```
/dev/ttySC0 SEND: c
```

```
/dev/ttySC1 RECV 1 total
```

```
/dev/ttySC1 RECV: c
```

```
/dev/ttySC1 SEND: a
```

```
/dev/ttySC0 RECV 1 total
```

```
/dev/ttySC0 RECV: a
```

ttySC0,ttySC1 分别发送数据，并能接收数据；

2.13 CAN 测试

测试方法：

在串口终端中执行以下命令

```
root@embest:~# ip link set can0 type can bitrate 50000 loopback on
```

```
root@embest:~# ip link set can0 up
```

```
[ 1080.870648] c_can_platform 481cc000.can can0: setting BTR=1c1d BRPE=0000
```

执行以下命令在后台接受数据包：

```
root@embest:~# candump can0 &
```

执行以下命令在发送数据包：

```
root@embest:~# cansend can0 123#11223344556677
```

```
can0 123 [7] 11 22 33 44 55 66 77
```

```
can0 123 [7] 11 22 33 44 55 66 77
```

关闭设备：

```
root@embest:~# ip link set can0 down
```

```
read: Network is down
```

```
root@embest:~# [ 1280.241265] c_can_platform 481cc000.can can0: setting BTR=1c1d BRPE=0000
```

2.14 网络测试

连接网线到 J17，在串口终端中输入以下命令来测试：

设置 IP 地址：

```
root@embest:~# ifconfig eth0 192.168.2.64
```

网络测试：

```
root@embest:~# ping 192.168.2.1
```

eth1 测试时，断开 J17 网线，连接外接网卡，执行同样的命令（eth0 改成 eth1）。

2.15 USB 测试

2.15.1 Host 测试

将 U 盘插入 USB host 接口 (P3)，串口显示磁盘信息:

```
[ 749.839750] usb 2-1: USB disconnect, device number 2
[ 753.033776] usb 2-1: new high-speed USB device number 3 using musb-hdrc
[ 753.174244] usb 2-1: New USB device found, idVendor=0781, idProduct=5530
[ 753.181112] usb 2-1: New USB device strings: Mfr=1, Product=2, SerialNumber=3
[ 753.189783] usb 2-1: Product: Cruzer
[ 753.193454] usb 2-1: Manufacturer: SanDisk
[ 753.198779] usb 2-1: SerialNumber: 20060876900F3042FBB5
[ 753.207733] usb-storage 2-1:1.0: USB Mass Storage device detected
[ 753.218483] scsi host1: usb-storage 2-1:1.0
[ 754.224988] scsi 1:0:0:0: Direct-Access    SanDisk  Cruzer           1.26 PQ: 0 ANSI: 5
[ 754.248822] sd 1:0:0:0: [sda] 7821312 512-byte logical blocks: (4.00 GB/3.72 GiB)
[ 754.261207] sd 1:0:0:0: [sda] Write Protect is off
[ 754.269365] sd 1:0:0:0: [sda] Write cache: disabled, read cache: enabled, doesn't support DPO or FUA
[ 754.291840]  sda:
[ 754.300985] sd 1:0:0:0: [sda] Attached SCSI removable disk
```

串口终端输入如下命令:

```
root@embest:~# ls /dev/sd*
/dev/sda
```

/dev 下存在设备节点;

2.15.2 OTG 测试

2.15.2.1 主设备

通过转接线连接 U 盘到 J13:

```
[ 777.452379] usb 2-1: USB disconnect, device number 3
[ 828.653766] usb 1-1: new high-speed USB device number 2 using musb-hdrc
[ 828.794284] usb 1-1: New USB device found, idVendor=0781, idProduct=5530
[ 828.801145] usb 1-1: New USB device strings: Mfr=1, Product=2, SerialNumber=3
[ 828.811356] usb 1-1: Product: Cruzer
[ 828.817391] usb 1-1: Manufacturer: SanDisk
[ 828.823054] usb 1-1: SerialNumber: 20060876900F3042FBB5
[ 828.834098] usb-storage 1-1:1.0: USB Mass Storage device detected
[ 828.848209] scsi host2: usb-storage 1-1:1.0
```



```
[ 829.854966] scsi 2:0:0:0: Direct-Access    SanDisk  Cruzer          1.26 PQ: 0 ANSI: 5
[ 829.879600] sd 2:0:0:0: [sda] 7821312 512-byte logical blocks: (4.00 GB/3.72 GiB)
[ 829.893393] sd 2:0:0:0: [sda] Write Protect is off
[ 829.902869] sd 2:0:0:0: [sda] Write cache: disabled, read cache: enabled, doesn't support DPO or FUA
[ 829.927923]  sda:
[ 829.939997] sd 2:0:0:0: [sda] Attached SCSI removable disk
```

串口终端输入如下命令：

```
root@embest:~# ls /dev/sd*
```

```
/dev/sda
```

/dev 下存在设备节点；

2.15.2.2 从设备

连接 J13 到 PC 端，打开设备管理器，识别到如下设备：



第3章 系统编译

3.1 配置编译环境

将 SBC-PH8700-Release-REV01 文件夹拷贝到 Linux 环境下的 \$HOME 目录下(解压 rar 文件), 编译工具 gcc-linaro-4.9-2015.05-x86_64_arm-linux-gnueabi 在 \$HOME/S5_Tool 目录下, 用如下命令解压:

```
$xz -d gcc-linaro-4.9-2015.05-x86_64_arm-linux-gnueabi.tar.xz
```

```
$tar -xvf gcc-linaro-4.9-2015.05-x86_64_arm-linux-gnueabi.tar
```

导入环境变量:

```
$export
```

```
CROSS_COMPILE=$HOME/S5_Tool/gcc-linaro-4.9-2015.05-x86_64_arm-linux-gnueabi/bin/arm-linux-gnueabi-
```

```
$export ARCH=arm
```

3.2 编译 UBOOT

3.2.1 获取 u-boot 源码

Uboot 源码在 \$HOME/S4_Sourcecode/ 目录下, 解压 u-boot*.tar.gz :

```
$ cd $HOME/S4_Sourcecode/
```

```
$ tar -zxvf u-boot*.tar.gz
```

3.2.2 编译并烧写镜像到 SD 卡

```
$ cd $HOME/S4_Sourcecode/u-boot
```

```
$ make distclean
```

```
$make som_ph8700_defconfig
```

```
$make
```

编译完成后在 \$HOME/S4_Sourcecode/u-boot 目录下生成 MLO, u-boot.img, 将两个文件拷贝到 SD 卡中;

3.2.3 编译并烧写镜像到 EMMC

```
$ cd $HOME/S4_Sourcecode/u-boot
```

```
$ make distclean
```

```
$make som_ph8700_emmcboot_defconfig
```

```
$make
```

编译完成后在 \$HOME/S4_Sourcecode/u-boot 目录下生成 MLO, u-boot.img, 将两个文件烧写到 EMMC 中;

(参考 [1.3 从 EMMC 启动系统](#))

3.3 Kernel

3.3.1 获取内核源码

内核源码存在\$HOME/S4_Sourcecode/目录下,解压 linux*.tar.gz

```
$ tar -zxvf linux*.tar.gz
```

3.3.2 编译并烧写镜像到 SD 卡

```
$ cd $HOME/S4_Sourcecode/linux
```

```
$ make distclean
```

```
$ make embest_ti_8700_defconfig
```

```
$ make
```

编译完成后在

- 目录\$HOME/release/sourcecode/linux/arch/arm/boot 下生成 zImage 文件。
- 目录 \$HOME/ release/sourcecode/linux/arch/arm/boot/dts 中生成下列 3 个文件:
 1. embest-SOM_PH8700-BB_SPH1800-4.3inch_LCD.dtb
 2. embest-SOM_PH8700-BB_SPH1800-7inch_LCD.dtb
 3. embest-SOM_PH8700_BB_SPH1800-HDMI.dtb

dtb 文件分别对应 4.3 寸屏, 7 寸屏, HDMI 显示 (配置方法参考 [LCD 测试](#), [HDMI 测试](#));

将文件拷贝到 SD 卡中。

单击下面可查看定价，库存，交付和生命周期等信息

[>>Avnet manufacturing service\(英蓓特\)](#)