Approved Checked Design	ed DEV	ELOPMEN'	Γ SPECI	FICATIO	N			
[] forgation [Topo	(o P	/N:LN	J 9 1 1 V	V8BRA				
T Y P E	Blue Lig	ht Emittir	ng Diode			<u> </u>	- 	
APPLICATION		Indicatiors						
MATERIAL								
OUTLINE	Attached						· · · · · · · · · · · · · · · · · · ·	
ABSOLUTE	P	*1 I _{FP}	I _{FDC}	V _R	Top	or	Tst	
MAXIMUM	40	50	10	5	-25~+85		-30~+100	
RATINGS	пW	mA	mΛ	V	$^{\circ}$ C		°C	
CONDITION $Ta = 25 \pm 3^{\circ}C$								
Test Specification								
l tem			- n	Tr	Limit		TI	
	Cymber		u i t .	———	Тур	Min	Max	Unit
Forward Voltage	V _F	I _F =	5 m A		3.2		3.7	V
Reverse Leakage Current	I _R	$V_R =$	5 V				10	μΑ
Luminous Intensity *2	I o	I _F =	5 m A	DC	8.5	4.5		mcd
Peak Emission Wavelength	λp	I _F =	5 m A	DC	470			nm
Spectral Line Half Width *1. The Condition of Du	L		5 m A	DC	30			nm

*1. The Condition of pulse current I_{FP} is 1ms pulse width, 10 % duty cycle.

*2. Tolerance of luminouse intensity $\pm 20\%$.

 Please contact the Panasonic local office if you design at low current (below 1 mA DC) or pulse current operation and have any questions.

NOTE

- ★1. Soldering conditions. Refer to Handling note.
- ★2. Care should be taken that soldering is done within 3-days after opening the dry package and reel.
- ★3. Compositions of the lead ····· Cu/Ni/Au plating
- ★4. This LED is sensitive to static electricity and care should be fully taken in handling it. Particularly, when an overvoltage is applied, which exceeds the absolute maximum rating of the LED, its energy damages the LED. Therefore, take utmost proactive measures against static electricity and surge as to building an assembly line and handling the LED halfway the process.
 - (1) Check the entire drive circuit including the power source. For example, a surge current, etc., generated at power-on/off must not exceed the absolute maximum rating of the LED. Also, insert an appropriate protective circuit into the LED drive circuit.
 - (2) Beware of destruction by static electricity in handling the LED. As proactive measures against static electricity, it is effective to earth your body (via $1M\Omega$), spread conductive mat on the floor, wear semiconductive work uniform and shoes, and use semiconductive containers. Also, be sure to earth the nose of a soldering iron. It is recommended to use an ionizer, etc., in the facility or environment where static electricity may be generated easily.

Sep. 1.1999		

Panasonic

KAGOSHIMA MATUSHITA ELECTPONICS CO., LTD

KB-H-022-018B


Approved Checked Designed DEVELOPMENT SPECIFICATION P/N: LNJ911W8BRA % I_F - V_F I_0 - T_a 100 Ta=25° C 50 500 30 300 e c Relative Luminous 10 100 Curr 5 50 3 30 σ σ 3 10 0 60 Forward Voltage V_{F} (V) Ambient Temperature Ta (°C) [0 -] F I_F - Ta Ta=25° 50 10 (pow) 10 5 \subset Φ Intensity 5 ∇ 0.5 Luminous 0 _ 0.1 30 50 100 80 Forward Current [, (mA) Ambient Temperature Ta (°C) Sep. 1.1999 KAGOSHIMA MATSUSHITA ELECTRONICS CO., LTD. Panasonic

Downloaded From Oneyac.com


KB++-022-018B

Approved	Checked	Designed					
10		Var	DEVELOPMENT SPECIFICATION	_	T	1	
(.) ken	ry	Talato	P/N: LNJ911W8BRA				

Relative Luminous Intensity Wavelength Characteristics



· Directive Characteristics




Relative Luminous Intensity (%)

Sep. 1.1999	
<u></u>	

Panasonic

KACOSH!MA MATSUSHITA ELECTRONICS CQ.LTD



单击下面可查看定价,库存,交付和生命周期等信息

>>Panasonic(松下)